




PROFESSIONAL CHEF'S TORCH OPERATING INSTRUCTIONS

NOTE: THIS TORCH IS INTENDED FOR USE BY PROFESSIONAL CHEFS ONLY

IMPORTANT: Read these instructions carefully and familiarize yourself with the product before fitting the appliance to the gas cartridge. Review the instructions periodically to maintain awareness. Retain these instructions for future reference.

ASSEMBLY:

1. Ensure that the gas control knob ③ is turned to the "OFF" position (turned fully clockwise), before attaching torch to the butane canister (Fig. 1).
2. Keep the butane canister upright when fitting it to the torch (Fig. 2).
3. Place the torch on top of the canister ⑤ lining up the notch on the canister with the protruding bar on the torch ④. Gently push down on the torch and gently twist the torch slightly clockwise until stopped (Fig. 3)



OPERATION:

1. Use only high quality Hollowick butane gas cylinders.
2. Make sure the "On/Off" control knob ③ is in the "OFF" position.
3. Turn the regulating knob ③ **counter-clockwise** to about 2/3 of a circle, the gas will blow out from the burner tube of the torch with a "hiss" sound, press the ignition button ② to ignite the flame at the burner tube ① (Fig. 4/ 5).
4. Adjust the flame size by turning the control knob ③ to either right (-) or left (+).

TURNING OFF AND STORAGE:

1. After use, ensure that the valve is fully shut (control knob turned fully **clockwise**) (Fig. 6).
2. Be sure the flame is extinguished and the burner has cooled down and no other flame is nearby.
3. When torch is cool, turn the torch counter-clockwise from the butane canister and quickly lift off the torch to disconnect (Fig. 7). Keep and store the torch and cylinder in a safe place, away from fire or heat.

CAUTIONS:

1. For professional use only.
2. Read directions before use.
3. Disconnect the butane canister from the torch when not in use.
4. Never attempt to repair a damaged torch.
5. Never modify the torch. This may cause the torch to become unsafe.
6. Always point away from face, body & clothing when using and igniting
7. Do not store under direct sunlight or any place where temperature will exceed 104°F.
8. Work only in well-ventilated areas.
9. Be aware that the torch and burner tube can get extremely hot during use- Do not touch!
10. Torch retains heat for several minutes after use. Do not touch!!
11. Take extra precautions to protect yourself and others from accidental burns.
12. Keep out of reach of children